

DOSATORE PNEUMATICO ABNOX ABNOX METERING VALVE



Art. 3230

Schema di montaggio
pag. 127

Assembly diagram
pag. 127

Dosatore automatico per grasso e olio particolarmente indicato per grandi quantità di prodotto. Il lubrificante viene portato al dosatore a mezzo di una pompa pneumatica a bassa pressione Art. 2000-2001-2002.

Il funzionamento avviene a mezzo di comando pneumatico o elettrovalvola fornita solo su richiesta.

Dotati di vite regolazione che permette la taratura del grasso secondo necessità. Una valvola 5/2 vie deve essere prevista.



Automatic metering valve for grease and oil especially suitable for large quantities of product. The lubricant must be carried to the dispenser by a low pressure air pump Art. 2000-2001-2002. Complete with an adjustment screw which can calibrate the grease to one's needs. The operation occurs through impulse of a pneumatic or electric valve supplied only on request. A 5/2 way valve is required.

Art. Art.	Dosaggio cm ³ Disp. range cm ³	Entrata In	Raccordi Connection	Uscita Out	Attacco aria Air connections	Pressione BAR Pressure BAR	Peso gr. Weight gr.
3230	2,0-26,0	G1/4		G1/4	G1/8	6	2087
3231	5,0-54,0	G1/4		G1/4	G1/8	6	2560
3232	10,0-133,0	G1/4		G3/8	G1/8	6	6570

Art. 3214

Dosatore automatico per grasso e olio con impugnatura speciale idoneo per linee di montaggio. Il lubrificante viene portato al dosatore a mezzo di una pompa a bassa pressione art. 2000 - 2001 - 2002.

Automatic grease and oil metering valve with special handle for assembling line. The lubricant must be carried to the dispenser by a low pressure air pump art. 2000 - 2001 - 2002.



Art. Art.	Dosaggio cm ³ Disp. range cm ³	Entrata In	Raccordi Connection	Uscita Out	Attacco aria Air connection	Pressione BAR Pressure BAR	Peso gr. Weight gr.
3214	0,05-0,45	G1/4		G1/8	M5	6	1196
3215	0,2-2,0	G1/4		G1/8	M5	6	1202
3216	1,0-6,0	G1/4		G1/8	M5	6	1657

A&G Martinelli